



## 3M Ammonia Methylamine Cartridge, Respiratory Protection

Model : 6004

### Product Details

- Ammonia and methylamine cartridge
- Swept-back design for enhanced field of view and balance
- Use with 3M™ Reusable Respirators



NIOSH approved against ammonia and methylamine. Use with 3M™ Half and Full Facepieces 6000, 7000 and FF-400 Series with bayonet filter holders.

Use in a variety of applications including agriculture, chemical manufacturing, laboratories and the food industry. When properly fitted, helps provide respiratory protection from ammonia and methylamine at concentrations up to 10 times the Permissible Exposure Limit (PEL) with half facepieces or 50 times PEL with full facepieces. Full facepieces must be quantitatively fit tested to claim assigned protection factor above 10 in negative pressure mode. Not for use in environments that are immediately dangerous to life or health (IDLH).

### Specifications

Cartridge or Filter Type	Cartridge
Gas & Vapor Protection Type	Ammonia and Methylamine
Height	3.4 Inch
Length	4.2 Inch
NIOSH Cartridge or Filter Assigned Color Coding	Green
Nuisance Odor Relief (< OSHA PEL)	AM/MA
Product Type	Cartridge
Recommended Application	Batch-Charging, Charging of Refrigeration Systems, Chemical Dispensing, Cleaning, Maintenance, Soil Preparation
Recommended Industry	agriculture, chemical manufacturing, laboratories and the food industry