

3M DBI-SALA Force2 Shock Absorbing Lanyard, Yellow

Model: 1246414

PRODUCT HIGHLIGHTS

- 6 ft. (1.8m) single-leg lanyard
- Transverse load rated self locking/closing aluminum Comfort Grip connector
- Force2™ 12 ft. free fall (3.6m) and dual capacity rated
- Extremely compact and lightweight
- Exclusive Vectran™ energy absorption system
- Abrasion resistant polyester webbing
- User friendly aluminum self locking snap hook
- Built-in reflective materials
- Impact indicator
- Protected labels, equipped with 3M™ Connected Safety ID (CSID)



6 ft. (1.8m) single-leg web Force2™ with aluminum snap hook at one end, aluminum Comfort Grip snap hook at leg end.

The Force2™ lanyard is ideal when there is no overhead anchorage and your only option is to tie off at your feet. It can be used for up to a 12 ft. (3.7 m) free fall, or as a standard lanyard up to a 6 ft. (1.8 m) free fall for workers that require a capacity of 311 to 420 lbs. (141 190 kg). This lanyard also features the DBI-SALA® Tie-Back Shock Absorbing Lanyard features including a 5,000 lb. (22 kN) gated hook and heavy duty abrasion resistant 13,000 pound (58 kN) tensile strength webbing, making it ideal for the rigors of tie back use. DBI-SALA® Tie-Back Shock Absorbing Lanyard eliminates the need for a separate anchorage connector, thus reducing inventory and cost, simplifying inspections, training and improving compliance. They feature the world's smallest and lightest shock absorber and our exclusive Vectran™ energy management materials that provide second to none abrasion, cut and chemical resistance and efficient shock absorption. Should a fall occur, the lanyard and it's unique energy absorbing system will activate stopping the fall and reducing the forces imposed on the user to safe levels. Our patented self locking snap hooks which are widely recognized in the industry for their user friendly operation and are preferred by safety professionals and workers alike. Specifically designed to allow you to open and connect the hook without getting your thumb or fingers in the way even with gloves on.

SPECIFICATIONS

Anchor Connection Type **Comfort Grip Snap Hook**

Brand **DBI-SALA®**

Connected Safety ID Equipped **Yes**

Energy Absorber Class **12 ft. (3.6 m) Free Fall/MAAF 1350 lbs. (6 kN)**

Harness Connection Type **Snap Hook**

Lanyard Type **Fixed**

Leg Count **Single-Leg**

Material **Polyester**

Number of Legs **1**

Overall Length (Imperial) **6 ft**

Product Color **Yellow**

Product Type **Shock Absorbing Lanyard**

Recommended Industry **Construction, General Industrial, Mining, Oil & Gas, Transportation, Utilities, Wind Energy**

Weight Capacity **130-310 lbs. (59-141kg) for 12 ft. (3.7m) Free Fall / 310-420 lbs. (141-190kg) for 6 ft. (1.8m) Free Fall**

Weight Capacity (Imperial) **420 lb.**

Weight Capacity (Metric) **190 kg**