

## 3M DBI-SALA Sayfline Cable Horizontal Lifeline System, 30 ft (9.1 m)

Model: 7602030

### Details

- Complete 30 ft (9.1 m) system includes termination, tensioner, and energy absorber
- Rugged 3/8 in (9.5 mm) 7x19 galvanized cable lifeline is durable and corrosion resistant for longer service life
- Lightweight and portable design provides fast, and easy handling, installation and storage
- Durable galvanized and zinc-plated steel construction are built to last and corrosion resistant
- Exclusive 3M™ DBI-SALA® Zorbit™ energy absorber limits fall arrest forces on the worker, minimizes fall clearance needed and protects the structure
- Unique wedgrip termination without special tools or cable clips for ease of use
- Flexible system provides protection of two workers
- Various lengths and individual components are available to completely customize your system
- Equipped with 3M™ i-Safe™ Identification Tag, for recording and storing information on inspections



The 30 ft (9.1m) 3M DBI-SALA Sayfline Cable Horizontal Lifeline System includes a wedgrip termination, turnbuckle tensioner, and 3M™ DBI-SALA® Zorbit™ Energy Absorber.

The 3M DBI-SALA Sayfline Cable Horizontal Lifeline System is highly portable and ideal for use in situations where welding, sparks, or harsh environments are present or where minimal clearance exists. This all-metal system is durable enough to be left in place for long periods of time and light enough to be moved easily from one job to another. Engineered with attention to quality and detail, the 3M™ DBI-SALA® Sayfline Systems will work alongside you during maintenance, bridgework, construction and manufacturing with safety and reliability. A horizontal lifeline may appear to be a basic line strung between two anchors, but it is not. These systems are used to protect workers operating in the horizontal plane who may not have continuous access to suitable anchorage points.





AUTHORIZED DISTRIBUTOR



Fall Protection



## Specifications

Brand	DBI-SALA®
Case Quantity	1
Connected Safety ID Equipped	Yes
Install Type	Temporary/Portable
Lifeline Material	Galvanized Cable
Maximum Number of Workers	2
Net Weight (Imperial)	23 lb
Net Weight (Metric)	10.4 kg
Overall Length (Imperial)	30 ft
Overall Length (Metric)	9.1 m
Pack or Case Quantity	1 each
Product Series	Sayflin
Product Type	Cable Horizontal Lifeline System
Recommended Industry	Construction, General Industrial, Mining, Oil & Gas, Transportation, Utilities
Span Type	Single-Span
Specifications Met	Capital Safety Gen. Mfg. Req., OSHA 1910.66
Weight (Imperial)	23 lb
Weight (metric)	10.4 kg
Weight Capacity	310 lbs. (141 kg)
Weight Capacity (Imperial)	310 lb
Weight Capacity (Metric)	141 kg



**Sheida International Co LLC** | Bait Qassim Building | Behind Sultan Centre | Qurum | Muscat | Sultanate of Oman | Email: [info@sheidainternational.com](mailto:info@sheidainternational.com) | Tel+ 968 92803889 | Web: [www.sheidainternational.com](http://www.sheidainternational.com) | [www.sheidasafety.com](http://www.sheidasafety.com)