

## 3M Flap Disc 769F, T29, 115 mm x 22.23 mm, 40+,

Model: 769F 40+



### Product Details

- Delivers long-lasting high performance and versatility at a value price
- Contains 3M Precision-Shaped Grain, which cuts faster and lasts longer than conventional abrasive grain
- Proven to outperform traditional alumina zirconia flap discs
- Individual flaps break down, exposing fresh mineral to deliver consistent cut rate for the life of the disc
- Ideal for use on mild steel, stainless steel and other heat-sensitive alloys
- Covers a wide range of applications from weld grinding and beveling to surface prep

In many cases, 3M™ Flap Disc 769F will allow you to grind and finish in one step, without changing abrasives. This is because, under normal conditions, 769F will generate a finish that is one grade finer than a fibre disc of the same grade. While a fibre disc will cut faster, this flap disc can eliminate steps and disc change outs to help save you time.

### Specifications

Brand	3M
Center Hole Diameter (Metric)	22.23 mm
Grit	40+
Industries	Metalworking
Inside Diameter (metric)	115 mm
Max RPM	13300
Overall Diameter (Metric)	115 mm
Product Form	Disc
Sub Industries	Metal Fabrication

