

3M Silver Cut-Off Wheel, T42, 115 mm x 2.5 mm x 22.23 mm,

Model: 51800

Product Details

- Cuts quickly through metal pipes, tubes, flat sheets and more
- Cuts quickly through metal pipes, tubes, flat sheets and more
- 3M Precision Shaped Grain cuts cleanly and fast, helping to increase productivity
- Long-lasting wheel provides great performance value
- Use with tools and accessories designed for cut-off wheels
- For safety, always use on a tool with an approved guard, as per ANSI B7.1



3M Silver Cut-Off Wheel is designed to deliver an unbeatable combination of performance and value. It cuts quickly through metal pipes, tubes and flat sheets. The long-lasting wheel uses our Precision Shaped Grain to deliver a fast, consistent cut.

Get a fast, consistent cut suitable for a variety of applications with 3M™ Silver Cut-Off Wheel. It cuts quickly and cleanly through metal pipes, tubes, flat sheets and more. The wheel features our Precision Shaped Grain, which continually fractures into super-sharp points and edges that slice cleanly through metal, rather than gouging or ploughing as traditional abrasives do. This helps it to last significantly longer than conventional ceramic grain abrasives while maintaining a high cut-rate over its life. It must be attached to a cut-off wheel tool (sold separately) and should always be used with a wheel guard for safety. The wheel also must have a maximum operating speed greater than or equal to the maximum speed of the power tool used.

Specifications

| | |
|-------------------------------|----------|
| Center Hole Diameter (Metric) | 22.23 mm |
| Max RPM | 13300 |
| Product Form | Wheel |
| Wheel Type | Type 42 |

