

PRODUCT FACT SHEET

Advanced™ Aluminum Tripod with Salalift™ II Winch

Model: 8300031

7 ft. (2.1 m) aluminum tripod and Salalift™ II winch with 60 ft. (18 m) of 1/4 in. (6.3 mm) stainless steel wire rope, mounting bracket and carrying bag.

PRODUCT HIGHLIGHTS

- 7 ft. (2.1 m) aluminum tripod (model 8000000)
- Telescoping adjustable locking legs
- Built-in pulley system
- Specialized safety shoes and leg support chain
- Integrated 5,000 lb. (22 kN) eyebolt anchor points
- Manually operated winch (model 8102003)
- 60 ft. (18 m) of 1/4 in. (6.3 mm) stainless steel wire rope
- 6:1 gear ratio mechanical advantage
- Free-wheel mode
- Built-in fall protection
- Overload clutch
- Swiveling snap hook with impact indicator
- Quick connect winch/SRL mount bracket
- Equipped with [i-Safe™](#)



Overview :

When it comes to confined space entry/rescue, it is essential that equipment operates perfectly and quickly. DBI-SALA® has an extensive line of rescue and retrieval systems with decades of proven field service. Safety engineers and site directors trust DBI-SALA® for the type of high quality, rugged systems that will ensure top performance when it is needed the most. Our aluminum tripods are extremely lightweight and portable, easily set-up by one worker and can be transported from one location to another. They can accommodate a variety of winches and fall arrest devices and feature locking legs, simple detent pin style adjustment, quick-mount mechanical device bracket, safety chain and specialized feet to prevent movement. Our mechanical systems are legendary and have decades of proven field service and have operated flawlessly in some of the most demanding jobsites around the globe. The mechanical device is one of the most critical parts of the rescue system providing the means to retrieve an incapacitated worker to safety. Lifeline type and length are just a few of the options.

SPECIFICATIONS

Capacity	350 lbs. (159 kg)
Brand	DBI-SALA®
Sub Brand	Advanced™
Size	60 ft. (18 m)
Install Type	Portable
Lifeline Type	Stainless Steel Cable
iSafe Equipped	Yes
Lifeline Length	60 ft. (18 m)
Hook	Zinc Plated Steel
Label	Mylar with Laminate
Winch/SRL Housing	Polyethylene, Anodized Aluminum
Lifeline	1/4" (6.4mm) dia. 7x19 Stainless Steel Aircraft Wire Rope
Model	8300031
Other Standards	ANSI Z117.1-1995, OSHA 1910.146
Physical Weight	80.40 lbs (36.5kg)
Product Styles	Complete System
Product Types	Tripod System
Standards	Capital Safety Gen. Mfg. Req.

Sheida International Co. LLC, ,P.O.Box 120, PC 114 Muscat,Sultanate of Oman

Email:info@sheidainternational.com, Web: www.sheidainternational.com