

## 3M DBI-SALA Cynch-Lok Pole Climbing Device, Rope

Model : 1204057

### Product Details

- Lightweight pole climbing design
- For distribution pole sizes 5.5" dia./17.5" circ. (14/45cm) minimum, 18.5" dia/58" circ. (47/147cm) maximum.
- Extremely durable pole strap with wear indicator
- One-handed effortless adjustment
- Pinch-free ergonomic grips
- Stopping cleat and carabiner
- Durable kernmantle rope with wear indicator
- Abrasion resistant sleeve
- Lightweight and durable rope adjuster
- Modular design with field replaceable straps
- Protected labels, equipped with i-Safe™
- Fall restriction device with rope lanyard for distribution poles up to 18.5" dia. (47cm), 58" circ. (147cm).



Cynch-Lok was developed with help from real pole climbers and features effortless adjustment and “cynches” around the pole during a “cut-out.” Cynch-Lok meets CSA Z259.14 standards for Type A and AB (dry, wet and icy poles) and ASTM F887. Cynch-Lok allows you to easily hitch-hike poles (move or jump the strap upwards) with a hand position that’s comfortable. It also moves past obstacles without difficulty. Exterior straps can easily be swapped out in the field depending on pole size, eliminating the need for multiple systems.

### Specifications

Anchor Connection Type	None
Brand	DBI-SALA®
Carabiner/Hook Material	Zinc Plated Steel
Case Quantity	1





<b>Color</b>	<b>Brown</b>
<b>Dimensions</b>	<b>18.5" dia./58" circ. (47/147cm)</b>
<b>Harness Connection Type</b>	<b>None</b>
<b>iSafe Equipped</b>	<b>Yes</b>
<b>Lanyard Type</b>	<b>Adjustable</b>
<b>Leg Count</b>	<b>None</b>
<b>Product Series</b>	<b>Cynch-Lok™</b>
<b>Product Type</b>	<b>Pole Climbing Device - Rope</b>
<b>Recommended Industry</b>	<b>Utilities</b>
<b>Size</b>	<b>18.5" dia./58" circ. (47/147cm)</b>
<b>Standards/Approvals</b>	<b>ASTM F887, ASTM F887-11, CSA Z259.14 Type A and B</b>
<b>Weight (Imperial)</b>	<b>4.8 lb.</b>
<b>Weight Capacity</b>	<b>310 lbs. (141 kg)</b>

