

PRODUCT FACT SHEET

EZ-Stop™ Tie-Back 100% Tie-Off Shock Absorbing Lanyard

Model: 1246070

6 ft. (1.8m) web double-leg 100% tie-off with adjustable D-rings for tie-back and snap hooks at ends.

PRODUCT HIGHLIGHTS

- 6 ft. (1.8m) double-leg 100% tie-off lanyard
- Tie-back style with adjustable D-rings
- Extremely compact and lightweight
- Exclusive Hi-10™ Vectran™ energy absorption system
- Dual-layer high strength/abrasion resistant webbing
- User friendly self locking snap hooks at each end
- Built-in reflective materials
- Impact indicator
- Protected labels, equipped with [i-Safe™](#)



Overview :

EZ-Stop™ shock absorbing lanyards combine a set of “industry-first” advancements, with popular features making them the workhorse of the industry. Today’s EZ-Stop™ represents the culmination of decades of design, research, manufacturing know-how and on-the-job performance. EZ-Stop™ lanyards are as tough as the guys who use them. They feature world’s smallest and lightest shock absorber, water-repellant and abrasion-resistant webbing and a build quality that is second to none. In addition, our exclusive Hi-10™ Vectran™ energy management materials provide second-to-none abrasion, cut and chemical resistance and efficient shock absorption. Should a fall occur, the lanyard and it’s unique energy absorbing system will activate stopping the fall and reducing the forces imposed on the user to safe levels. Our patented self-locking snap hooks which are widely recognized in the industry for their user friendly operation and are preferred by safety professionals and workers alike. Specifically designed to allow you to open and connect the hook without getting your thumb or fingers in the way - even with gloves on.

SPECIFICATIONS

Capacity	130-310 lbs. (59-141kg)
Brand	DBI-SALA®
Sub Brand	EZ-Stop™
Size	6 ft. (1.8m)
Velocity Ship	Yes
iSafe Equipped	Yes
Anchor Connector Hook Type	Snap Hook
Energy Absorber Class	6 ft (1.8 m) Free Fall/MAAF 900 lbs. (4 kN)
Harness Connector Hook Type	Snap Hook
Lanyard Type	Fixed
Number Of legs	Double-Leg 100% Tie-Off
Lanyard Length	6 ft. (1.8m)
Thread/Stitching	Polyester
Label	Vinyl
General Lanyard	Web
Harness Connection Hook	Zinc Plated Steel
Anchor Connection Hook	Zinc Plated Steel
Energy Absorber	Vectran™
Energy Absorber Cover	Nylon
Detailed Lanyard	1" (2.5cm) Polyester Web with 1-3/8" (3.5cm) Polyester Tubular Web
Model	1246070
Physical Weight	0.00 lbs (0.0kg)
Product Styles	Tie-Back
Product Types	Shock Absorbing Lanyard
Standards	OSHA 1910.66, OSHA 1926.502, Capital Safety Gen. Mfg. Req., ANSI A10.32

Sheida International Co. LLC, ,P.O.Box 120, PC 114 Muscat,Sultanate of Oman

Email:info@sheidainternational.com, Web: www.sheidainternational.com