

Lad-Saf™ X2 Detachable Cable Sleeve

PRODUCT FACT SHEET

Model: 6160030

Sleeve with carabiner, cam and inertial locking, fits 3/8" (9.5 mm) and 5/16" (8 mm) diameter 1x7 or 7x19 solid core cable.



PRODUCT HIGHLIGHTS

- Sleeve for Lad-Saf™ fixed ladder safety system
- For use on 3/8" (9.5 mm) and 5/16" (8 mm) 1x7 or 7x19 solid core cable
- Mobile design follows user for convenient climbing protection
- Easy to install and detach anywhere along lifeline
- Mechanical and inertial locking system stops falls within inches
- Built-in energy absorber and fall indicator
- Anti-inversion feature prevents incorrect installation
- Saflok™ steel carabiner for secure connection to harness
- Extremely rugged and corrosion resistant construction
- Extremely compact, lightweight design
- Order top and bottom brackets, cable and guides separately

Overview:

- The Lad-Saf™ flexible cable system consists of a top and bottom bracket that act as anchors for a steel cable that runs the length of the climbing area. A Lad-Saf™ X2 sleeve connects the worker to the system, automatically follows the user during the climb and locks onto the cable in the event of a fall, allowing the user to regain their footing. Designed for ease of use, economy and versatility, optional brackets/designs are available for bolting or welding the system, choose rung clamp sizes/styles, choose systems for straight or curved ladders and for connection to wood, concrete or steel structures. Hundreds of different brackets, styles and configurations are available to suit almost any application. In addition, the versatile system can be used by up to four workers simultaneously for added jobsite flexibility.



Now part of **3M**



SPECIFICATIONS

Capacity	310 lbs. (141 kg)
Brand	DBI-SALA®
Sub Brand	Lad-Saf™
Velocity Ship	Yes
iSafe Equipped	Yes
Label	Polyester, Stamped
Model	6160030
Physical Dimensions	4.70x1.30x6.00 (in)
Physical Weight	2.10 lbs (1.0kg)
Product Styles	Mobile
Product Types	Flexible Cable Ladder Safety
Standards	ANSI A14.3-1992, Capital Safety Gen. Mfg. Req.
Install Type	Temporary
Number Of Users	One
Structure Type	Straight Ladder

Sheida International Co. LLC, ,P.O.Box 120, PC 114 Muscat,Sultanate of Oman

Email: info@sheidainternational.com, Web: www.sheidainternational.com