

# BUCK LADDER TETHER



## BUCK LADDER TETHER(BLT) – 128R

Buckingham Manufacturing is proud to announce the Buck Ladder Tether. The patent-pending BLT is a ladder-mounted lifeline system that allows 100% fall protection for the user while ascending or descending. In the past, the 128R ladder lock straps were just wrapped around the ladder for storage. We have now introduced a weather-resistant storage bag for your ladder lock straps. This allows the user to stow the straps in a weather-resistant bag on the ladder while not in use. Straps also include a new wear guard to prevent long-term UV degradation if stored outdoors long term.

\*In the event of a fall from the ladder, the BuckArrester will arrest the fall while the Ladder Lock System keeps the ladder secured to the pole.



- Specially designed Ladder Lock System to secure ladder from ground, pole, or any other structure you may be working
- The BLT is especially ideal for substation work. We've tested the BLT in numerous scenarios and the BLT was able to provide fall protection in most, if not all, scenarios in the sub.
- The Ladder FP Anchor Strap attaches to the top of the ladder securing the lifeline to the ladder.
- Lifeline includes ANSI Z359.15 rated BuckArrester system allowing for 100% fall protection on ascent and descent.
- The BuckArrester design provides the user with smooth hands-free up and down tracking, allowing the user to maintain the required 3-point contact at all times.
- The ladder lock strap bag easily stays out of the way when the ladder is in use.
- The BLT is only intended for use with Type IA (300 lbs. rated) and IAA (375 lbs. rated) fiberglass extension ladder with a V-rung / V-bar installed to create a ladder mounted lifeline system.

Product Number:	128R		
Product Name:	Buck Ladder Tether (BLT)		
Kit Weight:	6.4 lbs.		
Product Number:	355TQ2	Product Number:	39Y8Q2-28
Product Name:	Buck Ladder Tether Ladder Straps	Product Name:	Ladder Tether Lifeline
Bag:		Length:	28'
Material:	Vinyl	Material:	7/16" Double Braid Rope
Height:	5.5"	Connector:	Steel Triple Action Carabiner (5005S3)
Width:	14"	Connector Standards:	ANSI Z359.12
Color:	BuckViz Green	MBS:	5,000 lbf. (22 kN)
Closure Type:	Hook & Loop Fastener	Standards:	ANSI Z359.15
Attach Type:	Quick Lock Buckles	Made in the USA?:	Yes
Thread Material:	Nylon		
Straps (2):		Product Number:	5004BQ1
Material:	Nylon Web	Product Name:	Ladder Fall Arrestor
Length:	20'	Length:	2.75"
Width:	1"	Width:	1.25"
Adjustment:	Cam Buckle	Connector:	Aluminum Carabiner w/ Captive Pin
Attach Type:	Snap / Dee Ring	Connector Standards:	ANSI Z359.12
Thread Material:	Nylon	Designed For:	7/16" Rope
Product Type:	Ladder / Fall Protection	MBS:	3,600 lbf. (16 kN)
MBS:	800 lbf. (3.55 kN)	Average Arresting Force:	900 lbf.
Standards:	N/A	Standards:	ANSI Z359.15
Made in the USA?:	Yes	Made in the USA?:	Yes
Product Number:	3912		
Product Name:	Ladder Anchor Sling		
Length:	37.5"		
Width:	1.75"		
Material:	Nylon web w/ outer tubing		
Connection Loops:	Yes		
# of Connection Loops:	2		
MBS:	5,000 lbf. (22 kN)		
Made in the USA?:	Yes		

### Authorised Distributor



Sheida International Co. LLC  
Safety Products and service  
PB: 120, PC: 114, Muscat, Sultanate of Oman  
Tel: +968 92803889. Web: [www.sheidasafety.com](http://www.sheidasafety.com)  
Email: [info@sheidainternational.com](mailto:info@sheidainternational.com)