

3M DBI-SALA Nano-Lok Twin-Leg Quick Connect Self Retracting Lifeline, Web

Model: 3101277

6 ft. (1.8m) twin-leg lifelines with 3/4" (19mm) Dyneema® fiber and polyester web and aluminum rebar hooks, quick connector for harness mounting.

PRODUCT HIGHLIGHTS

- Lightest ANSI certified personal SRL that allows for knee level tie-off
- Smart activating brake system combines ANSI Class A & B to provide fall clearance as low as 4 ft.- up to 13 ft. less than lanyards
- Lightweight speed connect system reduces connect and disconnect time by up to 60%
- Durable nitrile rubber energy absorber cover designed to last 4 times longer
- Reduced energy absorber size is more user friendly and convenient
- Twin-leg, 6 ft. (1.8m) 3/4" (19mm) Dyneema® fiber and polyester web lifeline
- AAF 900lbs and MAF 1,350lbs
- Down to knee level tie-off for 310lbs. capacity, 420lbs. capacity shoulder height and higher
- Aluminum self-locking snap hooks on lifelines
- 3M™ Connected Safety ID (CSID) equipped
- Wide variety of configurations available



SPECIFICATIONS

Anchor Hook Material	Steel
Brand	DBI-SALA®
Carabiner/Hook Material	Aluminum & Steel
Case Quantity	1
Connector	Single Pin Connector
Housing Material	Nylon Thermoplastic
Housing Type	Thermoplastic
Lifeline Hook Material	Aluminum & Steel



Lifeline Length (Imperial)	6 Linear Foot
Lifeline Length (Metric)	1.8 m
Lifeline Material	Web
Mounting Type	Direct to Harness Back
Overall Length (Imperial)	6 ft
Product Series	Nano-Lok™
Product Type	Twin-Leg Quick Connect Self Retracting Lifeline - Web
Recommended Industry	Construction, General Industrial, Oil & Gas, Transportation, Utilities
Standards/Approvals	ANSI Z359.14 Class A/B, OSHA 1926.502
Style	Dual Leg
Weight (Imperial)	5.767 lb.
Weight (Metric)	2.616 kg
Weight Capacity	420 lbs. (190 kg)

