

## Saflok™ Carabiner

### PRODUCT FACT SHEET

**Model: 2000112**

11/16 in. (17.5mm) gate opening steel carabiner with self closing/locking gate.

### PRODUCT HIGHLIGHTS

- 11/16 in. (17.5mm) gate opening steel carabiner
- Self closing and locking gate for added safety
- Highly corrosion resistant plated hardware
- High strength steel construction
- User friendly compact and lightweight design



### Overview:

- Our anchorage connectors are built from top quality materials guaranteeing high strength and durability to stand up to the toughest environments. Anchorage connectors are the unsung heroes of most fall protection systems, often overlooked but critical components because they securely attach your system to the anchorage. Your choice of anchor depends on the type of work being done. Anchorages are sold by what they connect to (general/all purpose, steel, concrete, roof or specialty), whether they are fixed or mobile, and whether they are permanent or portable. They all must provide a secure point of attachment for a complete personal fall arrest system, and must be capable of supporting a load of 5,000 lbs. (22kN) or of meeting OSHA's criteria of a 2-to-1 safety factor.

## SPECIFICATIONS

Attachment Type Info	Hook
Install Type	Reusable
Capacity	310 lbs. (141 kg) ANSI / 420 lbs. (190 kg) OSHA
Brand	DBI-SALA®
Sub Brand	Saflok™
Velocity Ship	Yes
iSafe Equipped	No
Label	Stamped
Hook	Zinc Plated Steel
Model	2000112
Physical Dimensions	4.33x2.66x0.75 (in)
Physical Weight	0.60 lbs (0.3kg)
Product Styles	Fixed
Product Types	Carabiner
Standards	OSHA 1910.66, OSHA 1926.502, ANSI Z359.1

*Sheida International Co. LLC, ,P.O.Box 120, PC 114 Muscat,Sultanate of Oman*

*Email:info@sheidainternational.com, Web: www.sheidainternational.com*