

Scotch Super 33+ Vinyl Electrical Tape, 3/4 in x 66 ft (19 mm x 20,1 m)

Model : Scotch® Super 33+

Product Details

- The combination of the pressure-sensitive, rubber-resin adhesive and the PVC backing offers electrical and mechanical protection
- Resists UV rays, abrasion, moisture, alkalis, solvents and acids
- Flame-retardant and inhibits the corrosion of electrical conductors
- Made of durable PVC
- Compatible with rubber and synthetic splicing compounds
- Withstands a temperature range of 0 to 221 °F (-18 to 105 °C)
- UL Listed, CSA Certified and RoHS 2011/65/EU Compliant



Scotch® Super 33+ Vinyl Electrical Tape is a 7 mil thick, premium grade tape that provides electrical insulation for all wires and cables rated up to 600V. The flame retardant tape withstands a temperature range of 0 to 221 °F (18 to 105 °C). It is compatible with solid dielectric cable insulation, synthetic cable insulations, jackets and splicing compounds.

Scotch® Super 33+ Tape is designed for above/below grade, indoor/outdoor, low and high voltage applications and for harnessing cables. This tape offers electrical and mechanical protection with the combination of a pressure sensitive, rubber resin adhesive and elastic, PVC backing. It provides a protective jacket for high voltage cable splices. This electrical tape is highly resistant to UV rays, abrasion, moisture, alkalis, solvents and many acids. UL Listed, CSA Certified and RoHS 2011/65/EU Compliant.

Specifications

Adhesion to Steel	28 oz/in.
Agency Approvals	CSA Certified, UL Listed
Applications	Insulation
Backing Material	Polyvinyl Chloride
Brand	Scotch®
Chemical Resistant	Yes
Elongation at Break	250%



Flame Retardant	Yes
Insulated	Yes
Insulation Resistance	> 10 ⁶ megohms
Maximum Operating Temperature	105 °C
Maximum Operating Temperature (Celsius)	105 Degree Celsius
Overall Length (Metric)	20 Meter
Overall Width (Metric)	19.05 mm
Product Type	Vinyl Electrical Tapes
RoHS EU Comments	RoHS 2011/65/EU compliant without exemption *Important RoHS information
Self-Extinguishing	Yes
Self Sticking/Amalgamating	No
Shelf Life in Months (from date of manufacture)	60
Suitable for High Voltage	No
Tape Grade	Premium
Tape Width (metric)	19 mm
Total Tape Thickness without Liner (metric)	0.178 mm
UV Resistant	Yes
Voltage Rating	600 V
Vulcanizing	No

