

PRODUCT FACT SHEET

## Sealed-Blok™ Self Retracting Lifeline

**Model: 3400650**

175 ft. (52.5m) of 3/16" (5mm) galvanized steel wire rope with swivel snap hook, anchorage carabiner, 4 ft. (1.2m) cable tie-off adaptor.

### PRODUCT HIGHLIGHTS

- Environmentally sealed dynamic components
- Extremely durable construction
- 175 ft. (52.5m) 3/16" (5mm) galvanized steel cable lifeline
- FAST-Line™ cable lifeline replacement system
- FAST-Line™ means LIFETIME field recertification - conditions apply
- Anti-ratcheting locking system
- Built-in carrying handle
- Swiveling snap hook with impact indicator
- Large pivoting anchorage loop
- Saflok™ anchorage carabiner
- Cable tie-off adaptor x 4 ft. (1.2m) with carabiner
- Reserve lifeline system
- Ergonomic cable handle equipped with [i-Safe™](#)



### Overview:

- These Sealed-Blok™ self retracting lifelines (SRL's) incorporate a patented concept that separates all dynamic components, including the motor spring and brake, from foreign elements such as grease, moisture and dirt. You can always trust your SRL to work at peak efficiency without worrying about the environment you're working in. Our sealed SRLs are backed by decades of proven field service for absolute confidence, safety and reliability. An SRL's lifeline will extend as the user moves away, and retract automatically enabling the user to move about within a recommended working area at normal speeds. Should a fall occur, a speed sensing brake system will activate stopping the fall and reducing the forces imposed on the user to safe levels.



Now part of **3M**

## SPECIFICATIONS



|                        |   |
|------------------------|---|
| <b>Capacity</b>        | 420 lbs. (190 kg)   |
| <b>Brand</b>           | DBI-SALA®   |
| <b>Sub Brand</b>       | Sealed-Blok™  |
| <b>Size</b>            | 175 ft. (53.3 m)  |
| <b>iSafe Equipped</b>  | Yes   |
| <b>Lifeline Length</b> | 175 ft. (53.3 m)  |
| <b>Lifeline</b>        | 3/16" (5mm) dia. 7x19 galvanized aircraft wire rope                     |
| <b>Lifeline Hook</b>   | Zinc Plated Steel   |
| <b>Housing</b>         | Aluminum, Stainless Steel   |
| <b>Anchorage Hook</b>  | Zinc Plated Steel   |
| <b>Model</b>           | 3400650   |
| <b>Physical Weight</b> | 100.00 lbs (45.4kg)   |
| <b>Product Styles</b>  | Single Lifeline   |
| <b>Product Types</b>   | Sealed Design   |
| <b>Housing Type</b>    | Metal   |
| <b>Lifeline Type</b>   | Galvanized Cable  |
| <b>Mounting Type</b>   | Overhead Anchor Point   |
| <b>Weight Group</b>    | Over 10 lbs. (4.5 kg)   |
| <b>Standards</b>       | OSHA 1910.66, OSHA 1926.502, Capital Safety Gen. Mfg. Req., ANSI A10.32 |

*Sheida International Co. LLC, ,P.O.Box 120, PC 114 Muscat,Sultanate of Oman*

*Email:info@sheidainternational.com, Web: www.sheidainternational.com*