

## 3M™ DBI-SALA® Ultra-Lok™ Heavy-Duty Self Retracting Lifeline, Cable

**Model: 3504485**

### Details

- Durable and lightweight cast aluminum housing
- Semi-sealed design
- 85 ft. (26m) 3/16" (5mm) galvanized steel cable lifeline
- Stainless steel dynamic components
- Internal energy absorption system
- Anti-ratcheting twin disk brake system
- Constant moving brake system pawls
- Swiveling anchorage point
- Swiveling snap hook with impact indicator
- Reserve lifeline system
- Ergonomic cable handle equipped with 3M™ Connected Safety ID (CSID)



85 ft. (26m) of 3/16" (5mm) galvanized steel wire rope with swivel snap hook.

Ultra-Lok™ self retracting lifelines (SRL's) are rugged, yet extremely lightweight and superbly engineered devices you can count on for safety, efficiency and comfort. Stainless steel components, an anti-ratcheting brake system and a semi-sealed design provide the user with a system built to last. Our SRLs are backed by decades of proven field service for absolute confidence, safety and reliability. An SRL's lifeline will extend as the user moves away, and retract automatically enabling the user to move about within a recommended working area at normal speeds. Should a fall occur, a speed sensing brake system will activate stopping the fall and reducing the forces imposed on the user to safe levels.

### Specifications

Brand	DBI-SALA®
Case Quantity	1
Dimensions	13.30x10.60x4.30in
Housing Material	Aluminum
Housing Type	Metal



iSafe Equipped	Yes
Lifeline Hook Material	Zinc Plated Steel
Lifeline Material	Galvanized Cable
Mounting Type	Block to Anchor Point
Overall Length (Imperial)	85 ft
Product Series	Ultra-Lok™
Product Type	Heavy-Duty Self Retracting Lifeline - Cable
Recommended Industry	Construction, General Industrial, Mining, Oil & Gas, Transportation, Utilities, Wind Energy
Standards/Approvals	ANSI Z359.1, ANSI Z359.14, OSHA 1910.66
Weight (Imperial)	33 lb.
Weight Capacity	310 lbs. (141 kg)

